

CIRCUIT INDEX

Table with 3 columns: CIRCUIT, ZONE, CIRCUIT, ZONE. Lists various electrical components like Air Conditioning, Battery, Choke, etc., and their corresponding zone numbers.





Table with 3 columns: CODE, COLOR, CODE, COLOR. Lists harness codes and their corresponding colors.

Table with 3 columns: CODE, HARNESS, CODE, HARNESS. Lists harness codes and their corresponding components.

COMPONENT LOCATIONS

Table with 3 columns: NAME, LOCATION ON VEHICLE, DIAGRAM ZONE. Lists various components like Air Blower Motor, Battery, Choke, etc., their locations, and diagram zone numbers.

CONNECTOR LOCATIONS

Table with 3 columns: CONNECTOR NO., LOCATION ON VEHICLE, DIAGRAM ZONE. Lists connector numbers, their locations, and diagram zone numbers.

GROUND LOCATIONS

Table with 3 columns: GROUND NO., LOCATION ON VEHICLE, DIAGRAM ZONE. Lists ground numbers, their locations, and diagram zone numbers.

