

SPECIAL INFORMATION

The Engine Build Code Number, the Vehicle Identification Number and the information provided on the Trim Plate are often necessary when determining the proper replacement parts for your vehicle. For their location refer to the General Information Section found at the front of this catalog.

NOTES

5-1 Used with Cable Clutch Linkage.

5-2 Used with Hydraulic Clutch Linkage.

NOTES

CLUTCH

5.054

GROUP NO. — DESCRIPTION — YEAR and MODEL	PAKS CODE	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
5.001-1 COVER ASSEMBLY, Clutch					
74/ 304.....			1	318 1383	
74/ SIX.....			1	318 1383	
74/ 360-401.....			1	318 4955	
5.040-1 PLATE, Driven					
74/75 SIX.....			1	318 4909	
76 SIX (10)(20)(40).....			1	318 4909	
74/75 304.....			1	318 4909	
74/ 360-401 (10)(20)(40).....			1	318 4867	
76 80-90.....			1	535 4689	
5.044-1 CONVERSION KIT, Right Hand Drive Hydraulic Clutch Linkage					
74/75 80 (RHD).....			1	812 7345	
5.050-1 BOLT, Clutch Cover To Flywheel					
74/.....			6	400 4165	
5.052-1 ADAPTER, Clutch Housing To Transmission					
W3ST					
74 10-25-40 (V8).....			1	998 547	
75/ 10-25-40 (V8).....			1	535 3897	
W4ST					
74/ SIX.....			1	992 667	
74 10-20-40 (V8).....			1	998 647	
75/ 10-20-40 (V8).....			1	535 3898	
5.052-2 ATTACHING PARTS, Adapter To Clutch Housing					
BOLT, Hexagon..... 74/ 10-20-40 (Six-W4ST).....	17.038		4	G180147	
BOLT, Hexagon..... 74/ 10-25-40 (360-W3ST).....	17.		2	G9419079	
BOLT, Hexagon..... 74/75 10-20-40 (V8-W4ST).....	17.038		4	G187137	
BOLT, Hexagon..... 76 10-20-40 (V8-W4ST).....	17.038		4	G443596	
BOLT, Hexagon..... 74/ 80 (W4ST).....	17.038		4	G180147	
STUD..... 74/ 10-20-40 (V8-W3ST).....	17.718		2	G103231	
WASHER, Lock..... 74/ W4ST.....	17.820		4	G120383	
WASHER, Lock..... 74/ 10-20-40 (Six-W4ST).....	17.820		4	G120214	
WASHER, Lock..... 74/ 10-25-40 (360-W3ST).....	17.820		4	G120383	
5.054-1 HOUSING, Clutch (Flywheel)					
74/75.....			1	321 5152	
76 10-20-40.....			1	321 5152	
76 80-90 (W3ST).....			1	322 3280	
76 80-90 (W4ST).....			1	322 8248	
5.054-1a STUD, Clutch Housing					
76 80-90 (W4ST).....			1	535 5564	
5.054-2 ATTACHING PARTS, Housing To Engine					
BOLT, Hexagon..... 74/ SIX... (7/16"-14 x 2-3/4").....	17.038		2	G180159	
BOLT, Hexagon..... 74/ V8... (3/8"-16 x 2-3/16").....	5.054		4	400 1885	
BOLT, Hexagon..... 74/ V8... (7/16"-14 x 2-3/4").....			2	400 4370	
BOLT, Hexagon..... 76 80-90... (3/8"-16 x 1-5/8").....	16.010		2	400 1883	
BOLT, Hexagon..... 76 80-90... (3/8"-16 x 2-3/16").....	5.054		3	400 1885	
BOLT, Hexagon..... 76 80-90... (7/16"-14 x 2-3/4").....			2	400 4370	
WASHER, Plain..... 74/ SIX.....	17.814		2	G120395	
WASHER, Lock..... 74/ SIX.....	17.820		2	G120383	
NUT, Hexagon..... 74/ SIX.....	17.406		2	G120377	
5.054-3 COVER, Clutch Housing					
74/.....			1	321 3744	
5.054-4 ATTACHING PARTS, Cover To Housing					
BOLT, Hexagon..... 74/ 10-20-40... (1/2" Long).....	17.038		2	G180073	
BOLT, Hexagon..... 75 10-20-40... (5/8" Long).....	17.626	AR		400 0987	
BOLT, Hexagon..... 74/ 80... (5/16"-18 x 5/8").....	17.038		3	G180075	
BOLT, Hexagon..... 76.....			4	400 0987	

5.054

CLUTCH

	WASHER, Lock	74/	17.820	2	G120214
	WASHER, Lock	74/	10-20-40 (V8-W3ST)	17.820	4	G120383
	NUT, Hexagon	74/	10-20-40 (V8-W3ST)	17.406	2	G271506
5.054-5	DOWEL, Clutch Housing					
	74			1.020	2	321 2857
	75/	2	400 5148
5.065-1	SPACER, Clutch Housing To Engine					
	74/			16.042	1	321 3743
5.065-2	ATTACHING PARTS, Spacer To Clutch Housing					
	BOLT, Hexagon	74/	10 (258)...(7/16"-14 x 2-1/4")	5.054	4	400 1885
	WASHER, Plain	74/	10 (258)	17.406	2	G120377
5.065-3	ATTACHING PARTS, Spacer To Cylinder Block					
	BOLT, Hexagon	74/	10 (258)...(1-1/8" Long)	16.010	1	400 1883
	BOLT, Hexagon	74/	20-40 (258)...(2-1/4" Long)	5.054	2	400 1885
5.109-1	SLEEVE, Clutch Throwout Lever (Incl. Bearing)					
	74/ 10-20-40 (Six)	1	535 0852
	74/ 10-20-40 (LHD-V8)	1	319 0517
	74/75 80	1	535 0852
	76 80-90	1	322 1236
5.123-1	LEVER, Clutch Throwout					
	74/75 LHD	1	321 7480
	74/75 RHD	1	999 848
	76 10-20-40	1	321 7480
	76 80-90	1	322 4192
5.123-2	WASHER, Lever To Clutch Throwout Lever Pin					
	74/75	1	317 8359
	76 10-20-40	1	317 8359
5.125-1	BOOT, Clutch Throwout Lever					
	74/75	1	317 3646
	76 10-20-40	1	317 3646
	76 80-90	1	318 0370
5.130-1	PIVOT ASSEMBLY, Clutch Throwout					
	74/75	1	318 4913
	76 10-20-40	1	318 4913
5.130-2	ATTACHING PARTS, Pivot To Housing					
	WASHER, Lock	74	11.170	1	400 4809
	WASHER, Lock	75	17.820	1	G120383
	WASHER, Lock	76	10-20-40	1	400 4809
5.130-3	BALL, Throwout Lever (In Clutch Housing)					
	74/			17.018	1	G169162
5.132-1	SPRING, Clutch Throwout Lever (In Clutch Housing)					
	74/75	1	319 9503
	76 10-20-40	1	319 9503
	76 80-90	1	322 2799
5.132-2	ANCHOR, Clutch Throwout Lever Spring					
	74/75	1	321 0423
	76 10-20-40	1	321 0423
5.135-1	PEDAL, Clutch					
	74/75 LHD	1	535 2649
	76 10-20-40	1	535 2649
	74 10-20-40 (RHD)	1	535 0619
	76 80-90 (LHD)	1	535 5313
	74/75 80 (RHD.* 5-1)	1	535 0626
	75 RHD (* 5-2)	1	535 4960
	76 80-90 (RHD)	1	535 5806

CLUTCH

5.160

5.135-3	ATTACHING PARTS, Clutch Pedal To Retainer			
	SNAP RING 74/	LHD.....	5.168	1 912 640
	PIN 74	10-20-40 (RHD)	8.160	1 939 023
	WASHER, Lock 74	10-20-40 (RHD)	17.820	1 G120384
	WASHER, Plain..... 74/	80.....	17.814	2 G120396
	WASHER, Lock..... 74/	80.....	17.820	1 G120384
	NUT, Lock 74	10-20-40 (RHD)	17.416	1 G443340
	NUT, Lock..... 74/	80.....	17.416	1 G443340
5.135-4	BEARING, Clutch Pedal			
	74.....			2 949 169
5.136-1	BRACKET, Clutch Pedal Retainer			
	74 10-20-40 (RHD-258)		8.164	1 535 0617
5.136-2	ATTACHING PARTS, Clutch Retaining Bracket To Dash			
	BOLT, Hexagon 74	10-20-40 (RHD)... (3/8"-16 x 7/8")	17.038	2 G180121
	BOLT, Hexagon 74	10-20-40 (RHD)... (3/8"-16 x 1")	17.038	2 G180122
5.144-1	COVER, Clutch Pedal Pad			
	74/.....		8.148	1 948 758
5.148-1	SHAFT, Clutch And Brake Pedal			
	74/ 10-20-40 (LHD).....			1 535 1805
	74/ 80 (LHD).....			1 535 1898
	74/ 80 (RHD)			1 999 582
5.148-2	ATTACHING PARTS, Brake And Clutch Pedal Shaft			
	NUT, Lock..... 74/ 80.....		18.190	1 400 4311
5.148-3	COLLAR, Brake And Clutch Pedal Shaft			
	74/ 80 (RHD)			1 999 554
5.148-4	SPACER, Clutch And Brake Pedal			
	74 10-20-40.....			1 535 1057
5.155-1	SPRING, Clutch Pedal Return			
	75 80 (RHD)			1 998 762
5.155-2	SPRING, Clutch Pedal Over Center			
	74/ LHD.....			1 535 1118
	74/75 RHD			1 932 923
5.155-3	ATTACHING PARTS, Spring To Clutch Pedal			
	CLEVIS 74/ RHD			1 937 795
	PIN, Cotter 74/ RHD		17.460	1 G112726
	PIN, Clevis 74/ RHD		17.474	1 G138083
	WASHER 74/ 80 (RHD)		17.814	1 G120396
5.160-1	ROD, Bellcrank To Clutch Pedal Shaft			
	74/75 10 (LHD)....(18-5/8" Long).....			1 535 1143
	74 10-20-40 (RHD)			1 941 447
	74 75 20-40 (LHD)....(15-9/16" Long).....			1 535 1144
	74 80 (LHD)....(18-1.2" Long).....			1 535 1302
	74/75 80 (LHD)....(18-3/8" Long).....	(Use 535 1302)		1 535 4705
	76 80-90 (LHD).....			1 535 3251
5.160-1a	ROD, Clutch Pedal To Link			
	75/ 10-20-40.....			1 535 5060
5.160-1b	ROD, Link To Clutch Bellcrank			
	75/ 10.....			1 535 5061
	75/ 10-40.....			1 535 5062
5.160-1c	LINK, Clutch Release Rod			
	75/ 10-20-40.....			1 535 5063

5.160

CLUTCH

5.160-1d ATTACHING PARTS, Link To Rod

NUT, Hexagon.....	75/	10-20-40 (Right Hand Thread)	17.410	1	G124824
NUT, Hexagon.....	75/	10-20-40 (Left Hand Thread)	1	400 4966

5.160-2 ATTACHING PARTS, Rod To Pedal

PIN, Lock	76	80-90 (LHD).....	1	400 0407
WASHER, Plain.....	76	80-90 (LHD).....	1	400 4437
WASHER, Spring.....	76	80-90 (LHD).....	1	321 5893
NUT, Hexagon.....	74/75	LHD.....	17.412	1	G271193

5.160-3 BALL JOINT, Adjusting Link

74/75	LHD.....	1	931 583
-------	----------	-------	-------	---	---------

5.160-4 ATTACHING PARTS, Locking Ball Joint To Rod

NUT, Jam.....	74/	LHD.....	17.410	1	G124925
---------------	-----	----------	--------	---	---------

5.160-5 ATTACHING PARTS, Ball Joint To Bellcrank

NUT, Hexagon.....	74/	10-20-40 (LHD).....	17.412	2	G271193
-------------------	-----	---------------------	--------	---	---------

5.160-6 BOOT, Clutch Pedal Rod Seal

74/	10-20-40 (LHD).....	1	535 1466
74	10-20-40 (RHD)	1	941 456
74/75	80 (LHD).....	1	535 1375
76	80-90 (LHD).....	1	322 0102

5.160-6a RETAINER, Clutch Push Rod Boot

74/	10-20-40 (LHD).....	1	535 1134
74/75	80 (LHD).....	1	535 1377
76	80-90 (LHD).....	1	535 5322

5.160-6b CLAMP, Clutch Pedal Push Rod Boot

74/	10-20-40 (LHD).....	(Use 934 246)	1	934 245
74/75	80 (LHD).....	4.160	1	318 1643

5.160-6c ATTACHING PARTS, Boot And Retainer To Floor Pan

SCREW, Tapping.....	74/	10-20-40 (LHD).....	17.670	3	G451824
SCREW, Tapping.....	74/75	80 (LHD).....	17.660	3	G163098
SCREW, Tapping.....	76	80-90 (LHD).....	17.660	3	G163210

5.160-8 ATTACHING PARTS, Rod To Bellcrank

PIN, Lock	76	80-90 (LHD).....	29.162	1	400 0407
WASHER, Plain.....	76	80-90 (LHD).....	1	400 4437
WASHER, Spring.....	76	80-90 (LHD).....	1	321 5893
NUT, Hexagon.....	74	10 (LHD).....	17.412	2	G271193
NUT, Hexagon.....	75/	10-20-40.....	17.412	2	G271193

5.160-9 BUSHING, Clutch Rod Retainer To Floor

76	80-90 (LHD).....	1	317 3461
----	------------------	-------	-------	---	----------

5.161-1 CABLE, Clutch Release

74	10 (RHD-W3ST)	(Use 812 2222)	1	535 0593
74	10 (RHD-W4ST)	(Use 812 2218)	1	535 0592
74	20-40 (RHD-W3ST).....	(Use 812 2219)	1	535 1129
74	20-40 (RHD-W4ST).....	(Use 812 2222)	1	535 0593
74/	80 (RHD-W3ST)	1	812 2226
74/	80 (RHD-W4ST)	1	812 2227

5.161-2 ATTACHING PARTS, Clutch Cable To Clutch Pedal (Pedal End)

CLEVIS.....	74/	80 (RHD).....	1	948 416
PIN, Clevis	74/	80 (RHD)...(1/4" O. D.).....	1	930 352
PIN, Clevis	75	80 (RHD)...(5/16" O. D.).....	17.474	1	G9411483
PIN, Cotter	74/	RHD.....	17.460	1	G137168

CLUTCH

5.165

5.161-2a	ATTACHING PARTS, Clutch Cable To Bellcrank				
	CLIP	74 10-20-40 (RHD)	1	819 311	
	PIN, Self-Locking.....	74/ 80 (RHD).....	28.053	1	974 250
	PIN, Lock	75 80 (RHD).....	29.162	1	400 0407
	PIN, Cotter	74/ 80 (RHD).....	17.460	1	G137168
	WASHER, Plain.....	74/ 80 (RHD).....	17.814	1	G120392
5.161-2b	ATTACHING PARTS, Clutch Cable To Throwout Lever				
	NUT, Ball (Adjusting) ..	74/ RHD.....	17.406	1	998 666
	NUT, Hexagon.....	74/ RHD.....	17.406	1	G120368
5.161-3	CLIP, Clutch Cable To Dash Panel And Engine Mounting Bracket				
	74 10-20-40 (RHD)	17.134	1	G120524	
	74/ 80 (RHD).....	8.192	2	930 061	
5.161-4	ATTACHING PARTS, Clip To Front Floor Pan				
	SCREW, Tapping.....	74 10-20-40 (RHD)	17.660	1	G9416843
	CLIP, Closed	74/ 80 (RHD).....	3.165	1	644 106
5.161-5	BOOT, Clutch Cable				
	74/ RHD.....			1	999 849
5.161-6	ATTACHING PARTS, Boot To Clutch Cable				
	CLAMP, Hose	74/ RHD.....	17.108	1	G272842
5.164-1	STOP, Clutch Pedal				
	74/ (Rubber) 10-20-40 (LHD).....			1	400 4828
	74/ (Rubber) 10-20-40 (RHD)	8.140	1	930 356	
	74 (Bolt) 10-20-40 (RHD).....			1	949 174
	76 80-90.....			1	535 5312
5.164-2	ATTACHING PARTS, Pedal Stop To Clutch Pedal Retaining Bracket				
	BOLT, Hexagon	74/ 10-20-40 (LHD).....	17.412	1	400 4826
	NUT, Hexagon.....	74/ 10-20-40 (LHD).....	17.412	1	G271193
5.165-1	BRACKET, Clutch Control Cable (Front Floor Pan)				
	74/ 80 (RHD).....			1	535 0621
5.165-2	ATTACHING PARTS, Bracket To Dash Panel At Steering Column Mount				
	BOLT, Hexagon	75 80 (RHD) ... (3/4" Long)	17.038	2	G181595
	BOLT, Hexagon	74/ 80 (RHD) ... (1-1/4" Long)	17.038	1	G123774
	BOLT, Hexagon	74/ 80 (RHD) ... (2" Long)	17.038	1	G181620
	WASHER, Lock	74/ 80 (RHD).....	17.820	2	G120214
	NUT, Hexagon.....	74/ 80 (RHD).....	17.406	2	G120368
5.165-3	BRACKET, Clutch Cable Anchor (To Transfer Case To Transmission)				
	74/ RHD.....			1	999 856
5.165-4	SPACER, Clutch Cable Bracket (Transfer Case To Transmission)				
	74/ RHD.....			1	992 731
5.165-5	SPACER, Clutch Cable Bracket To Transmission				
	74/ RHD.....			1	992 732
5.165-6	ATTACHING PARTS, Bracket To Transfer Case				
	WASHER, Lock	74/ 10-20-40 (RHD)	17.820	1	G120383
5.165-7	ATTACHING PARTS, Bracket To Transmission				
	BOLT, Hexagon (Nylock) 74/ RHD... (3/8"-16 x 1-5/8")			2	535 0658
	BOLT, Hexagon (Nylock) 74/ RHD... (7/16"-14 x 1-1/4")	5.160	1	998 599	
	WASHER, Lock	74/ RHD.....	8.186	2	649 704
5.165-8	BRACE, Clutch Cable Bracket To Transfer Case				
	74/ RHD.....			1	999 981
5.165-9	ATTACHING PARTS, Brace To Clutch Cable Bracket				
	NUT, Hexagon.....	74/ RHD.....	17.412	2	G271193

5.168

CLUTCH

5.168-1	BELLCRANK, Clutch Release Idler						
	74	10-20-40 (LHD)	(Use 535 4027)	1	535 2656
	75/	10-20-40 (Six)	1	535 4027
	75/	10-20-40 (V8)	1	535 4072
	74	80 (LHD-Used With 5-3/8" Long Release Rod)	1	535 1292
	74/75	80 (LHD-Used With 6" Long Release Rod)	1	535 4659
	76	80-90 (LHD)	1	535 3252
5.168-2	BELLCRANK, Upper Clutch Release						
	74	10-20-40 (RHD)	1	535 3375
5.168-3	BRACKET, Bellcrank Retaining						
	74	10-20-40 (RHD)	1	535 3368
	76	80-90	1	812 6589
5.168-4	ATTACHING PARTS, Bellcrank To Bracket						
	BUSHING (Brass)	74	10 (RHD)	2	911 236
	SPACER	74	10-20-40 (RHD)	1	941 730
	BOLT, Hexagon	74	10-20-40 (RHD)	17.038	1	G124100
	NUT, Hexagon	74	10-20-40 (RHD)	17.412	1	G271187
5.168-5	ATTACHING PARTS, Bracket To Floor Pan And Retainer						
	BOLT, Hexagon	74	10-20-40 (RHD)	17.038	2	G121661
	WASHER, Lock	74	10-20-40 (RHD)	17.820	2	G120214
	NUT, Hexagon	74	10-20-40 (RHD)	17.406	2	G120368
5.168-6	BRACKET, Support Clutch Release Idler Pivot Outer						
	74/	10-20-40 (LHD)	1	535 1135
	74/75	80 (LHD)	1	535 1285
	76	80-90 (LHD)	1	535 5339
5.168-7	ATTACHING PARTS, Outer Support Bracket To Frame Assembly						
	BOLT, Hexagon	74/75	LHD	17.671	2	G9424824
	NUT, Hexagon	76	10-20-40	17.671	2	G9424824
	NUT, Hexagon	76	80-90 (LHD)	2	400 1457
5.168-9	PIVOT, Clutch Release Idler						
	74/	10-20-40 (Six)	2	944 666
	74/75	80 (LHD)	2	944 666
5.168-10	ATTACHING PARTS, Clutch Release Idler Pivot To Support Bracket						
	WASHER, Lock	74/	LHD	17.820	1	G120383
	NUT, Hexagon	74/	LHD	17.406	1	G271506
5.168-11	SUPPORT, Clutch Release Idler Pivot						
	74/	10-20-40 (LHD-Six)	1	535 1271
	74/	10-20-40 (LHD-V8)	1	535 1112
	74/75	80 (LHD)	1	535 1284
	76	80-90 (LHD)	1	535 5332
5.168-11a	SPACER, Inner Bellcrank Bracket To Clutch Housing						
	74/	80 (Six-LHD)	4	535 1306
5.168-12	ATTACHING PARTS, Support Assembly To Clutch Housing						
	BOLT, Hexagon	74/	10-20-40 (LHD)	17.038	2	G186677
	BOLT, Hexagon	74/	80 (LHD-Six)	17.	2	G454871 NA
	BOLT, Hexagon	74/75	80 (LHD-V8)	17.038	2	G186677
	BOLT, Hexagon	76	80-90 (LHD)	17.038	1	G186677
	WASHER, Lock	74/	LHD	17.820	2	G120214
	NUT, Hexagon	74/	LHD	17.406	2	G271506
5.168-14	BOOT, Clutch Pivot Outer						
	74/	LHD	1	316 7049

CLUTCH

5.207

5.168-15	BOOT, Clutch Pivot Inner 74/ LHD.....		1	316 7049
5.168-16	BUSHING, Clutch Release Idler Pivot Inner (White Or Black Plastic) 74/ LHD.....		1	316 7067
5.168-17	BUSHING, Clutch Release Idler Pivot Outer 74/ LHD.....		1	316 7067
5.168-18	RETAINER, Clutch Release Idler Pivot Bushing Outer 74/ LHD.....		1	316 9769
5.168-19	FITTING, Lubrication (Bellcrank, Clutch Release Idler) 74 LHD.....	17.290	1	G271287
5.187-1	ROD ASSEMBLY, Clutch Fork Release			
	74/ 10-20-40 (LHD-Six)...(8-5/32" Long).....		1	535 1274
	74/ 10-20-40 (LHD-V8).....		1	535 1211
	74 80 (LHD)...(5-3/8" Long).....		1	535 1275
	74 75 80 (LHD)...(6" Long).....		1	535 4703
	76 80-90 (LHD).....		1	535 5345
	75 80 (RHD).....		1	535 4975
	76 80-90 (RHD).....		1	535 5821
5.187-2	ATTACHING PARTS, Rod To Bellcrank			
	NUT, Hexagon..... 74/ 10-20-40 (LHD).....	17.412	1	G271193
	NUT, Hexagon..... 76 80-90 (LHD).....	17.412	1	G271193
5.187-3	ADJUSTER, Clutch Wear 74/.....		1	535 1209
5.187-4	ATTACHING PARTS, Adjuster To Clutch Release Rod			
	NUT, Jam..... 74/ 10-20-40 (LHD).....	17.410	1	G124925
	NUT, Jam..... 74/75 80.....	17.412	1	G271193
	NUT, Jam..... 76 80-90 (LHD).....	17.410	1	G124925
5.187-5	SEAL, Clutch Wear Adjuster To Throwout Lever 74/.....	5.160	1	313 0998
5.190-1	SPRING, Clutch Throwout Lever Return			
	74/ LHD.....		1	535 1252
	74/75 RHD (* 5-1).....	8.192	1	644 067
	75/ RHD (* 5-2).....		1	535 1252
5.190-2	BRACKET, Clutch Throwout Lever Return Spring (Clip) 74/75 RHD.....		1	998 673
5.190-3	ATTACHING PARTS, Bracket To Clutch Housing			
	BOLT, Hexagon..... 74/ RHD.....	17.038	1	G180077
	WASHER, Lock..... 74/ RHD.....	17.820	1	G120214
5.207-1	CYLINDER ASSEMBLY, Clutch Master 75/ 80 (RHD).....		1	535 4977
5.207-2	PLATE, Clutch Master Cylinder Reinforcement 75 80 (RHD).....		1	535 4972
5.207-3	ATTACHING PARTS, Clutch Master Cylinder			
	BOLT, Hexagon..... 75/ 80 (RHD).....	17.	2	G180079
	NUT, Hexagon..... 75/ 80 (RHD).....		2	400 1547
5.207-5	END, Clutch Master Cylinder Push Rod 75/ 80 (RHD).....		2	535 4962
5.207-6	ATTACHING PARTS, End To Clutch Pedal			
	WASHER, Lock..... 75/ 80 (RHD).....	17.814	1	G120394
	PIN, Cotter..... 75/ 80 (RHD).....	3.200	1	G121222
5.207-7	ATTACHING PARTS, Rod End To Master Cylinder Push Rod NUT, Hexagon..... 75/ 80 (RHD).....	17.406	1	G120368

5.213

CLUTCH

5.213-1	TUBE, Hydraulic Clutch				
	75 80 (RHD).....	1	545 4976	
	76 80-90 (RHD).....	1	535 5822	
5.213-2	CONNECTOR, Hydraulic Tube To Master Cylinder				
	75/ 80 (RHD).....	5.217	1	535 4973	
5.213-3	WASHER, Hydraulic Tube Connector				
	75/ 80 (RHD).....	8.855	1	400 4838	
5.213-4	ATTACHING PARTS, Hydraulic Clutch Tube To Dash				
	CLIP, Closed 75/ 80 (RHD).....	17.134	1	G120521	
	SCREW, Tapping 75/ 80 (RHD).....	17.660	1	G9416843	
5.216-1	HOSE, Hydraulic Clutch				
	75/ 80 (RHD).....	1	535 4971	
5.216-2	FITTING, Bolt Hydraulic Clutch Hose To Slave Cylinder				
	75/ 80 (RHD).....	1	322 5702	
5.216-3	WASHER, Hydraulic Hose To Slave Cylinder				
	75/ 80 (RHD).....	2	400 4970	
5.221-1	CYLINDER ASSEMBLY, Clutch Slave				
	75/ 80 (RHD).....	1	535 4978	
5.221-2	BRACKET, Clutch Slave Cylinder				
	75/ 80 (RHD).....	1	535 4963	
5.221-3	ATTACHING PARTS, Clutch Slave Cylinder Bracket To Engine Block				
	BOLT, Hexagon 75/ 80 (RHD).....	17.629	2	812 1298	
5.221-4	ATTACHING PARTS, Clutch Slave Cylinder To Bracket				
	BOLT, Hexagon 75/ 80 (RHD).....	17.038	2	G180124	
	NUT, Hexagon..... 75/ 80 (RHD).....	10.260	2	400 3909	