

SPECIAL INFORMATION

The Engine Build Code Number, the Vehicle Identification Number and the information provided on the Trim Plate are often necessary when determining the proper replacement parts for your vehicle. For their location refer to the General Information Section found at the front of this catalog.

NOTES

SHIFTING

7.013

GROUP NO. — DESCRIPTION — YEAR and MODEL	PAKS CODE	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
7.001-1 LEVER, Floor Gear Shift (Incl. Fulcrum And Pin)					
74/75 (T14A) 10-25-45			1	812 3032	
76 10-20-40 (W3ST)			1	812 3032	
74/75 (T14A) 80			1	812 2131	
74 (T15A) 20-40 (Six)			1	991 093	
74/75 (T15A) 10-20-40 (V8)			1	812 3032	
74/75 (T15A) 80			1	812 1324	
74/ 10-20-40 (W4ST)			1	992 882	
74/ 80 (W4ST)			1	812 2422	
76 80-90 (W3ST)			1	812 6832	
7.001-2 FULCRUM, Floor Gear Shift Lever (Ball)					
74/75 W3ST			1	642 761	
76 10-20-40			1	642 761	
7.001-3 SPRING, Floor Gear Shift Lever Fulcrum					
74/75 W3ST			1	642 763	
74/ W4ST			1	801 732	
76 10-20-40			1	642 763	
76 80-90			1	812 7059	
7.001-4 PIN, Floor Gear Shift Lever Fulcrum					
74/75 W3ST			1	642 762	
76 W3ST (10)(20)(40)			1	642 762	
74/ W4ST			1	912 374	
76 80-90			2	812 6833	
7.001-5 RETAINER, Fourspeed Transmission Floor Gear Shift Lever Fulcrum Spring					
74/			1	912 379	
7.013-1 COVER, Floor Gear Shift Lever					
74/75 10-80 (LHD-W4ST)			1	948 185	
74/75 80 (W3ST)			1	907 107	
76 80-90			1	948 185	
7.013-1a RETAINER, Floor Gear Shift Lever Cover					
74/75 10-80 (LHD-W4ST)			1	948 146	
74/75 80 (W3ST)			1	649 890	
76 80-90			1	948 146	
7.013-1b ATTACHING PARTS, Retainer And Cover To Floor Pan					
SCREW, Tapping..... 74/75 10-80 (LHD-W4ST)	17.660		4	G161901	
SCREW, Tapping..... 74/75 80 (W3ST)	17.660		4	G161895	
SCREW, Tapping..... 76 80-90	12.128		4	400 3088	
NUT, Spring..... 75 10 (LHD-W4ST)	20.005		4	979 975	
7.013-2 BOOT, Floor Gear Shift Lever					
74 (Black) 10			1	545 0267	
75/ (Blue) 10-20-40 (LHD)			1	545 4789	
75/ (i hardware) 10-20-40 (LHD)			1	545 3643	
74 (Green) 10			1	545 0269	
75/ (Green) 10-20-40 (LHD)			1	545 5539	
74 (Tan) 10			1	545 2587	
75/ (Tan) 10-20-40			1	545 5540	
7.013-2b CAP, Transmission Control Housing					
76 80-90 (W3ST)			1	812 7446	
74/ W4ST			1	912 380	
7.013-2c GASKET, Transmission Cap Control Housing					
76 80-90 (W3ST)			1	812 6831	
7.013-3 RETAINER, Floor Gear Shift Lever Boot					
74/75 10-80			1	545 0203	
76 10-20-40			1	545 0203	
7.013-4 ATTACHING PARTS, Retainer To Floor Pan					
SCREW, Tapping..... 74 W3ST... (10-12 x 5/8")	4.131		3	973 467	
SCREW, Tapping..... 74/75 10-20-40 (WFGS)	17.660		4	G161903	
FASTENER (Plastic) ... 76 10-20-40	18.128		4	400 4919	

7.020

SHIFTING

7.020-1	LEVER, Column Gear Shift Upper				
	74/ WHT (LAW) ... (Incl. Knob)	1	535	1231	
	74/ WHT (WAW) ... (Incl. Knob)	1	535	2720	
7.020-2	ATTACHING PARTS, Upper Lever To Shaft				
	<i>PIN, Roll</i> 74/ 10-20-40 (RHD)	1	930	868	
7.020-3	PIN, Column Gear Shift Upper Lever Pivot				
	74/ WHT	1	400	3925	
7.020-6	HOUSING, Column Gear Shift Upper Lever				
	74/ 10-20-40 (LHD-WHT-WAW)	1	319	6538	
	74/ 10-20-40 (LHD-LAW)	1	448	9040	
	76 90 (WHT)	1	448	9040	
7.020-7	PLATE, Column Gear Shift Upper Lever Housing Lock				
	74/ 10-20-40 (LHD-WHT-WAW)	1	448	7860	
7.020-9	SPRING, Column Gear Shift Upper Lever Tension				
	74/ 10-20-40 (LHD-LAW)	1	448	7791	
	74/ 10-20-40 (LHD-WHT-WAW)	1	812	0251	
	76 90 (WHT)	1	448	7791	
7.020-10	BEARING, Gear Shift Upper Lever Housing				
	74/ 10-20-40 (LHD-WHT-WCGS-LAW)	1	448	7716	
	76 90 (WHT)	1	448	7716	
7.020-11	BUSHING, Column Gear Shift Upper Lever				
	74/ 10-20-40 (RHD)	1	941	100	
7.020-12	WASHER, Gear Shift Upper Lever Housing				
	74/ (Thrust) 10-20-40 (LHD-WHT-WAW)	1	448	7872	
	74/ (Wave) 10-20-40 (LHD-WHT-WAW)	1	448	7873	
7.030-1	KNOB, Gear Shift Lever				
	74/75 W3ST	1	929	393	
	76 W3ST	1	535	5939	
	74/75 W4ST	1	934	392	
	76 W4ST	1	535	5940	
7.030-2	ATTACHING PARTS, Knob To Lever				
	NUT, Jam 74 W4ST	17.410	1	G124925	
7.038-1	SHAFT, Gear Shift Operating (Inner)				
	74/ 10-20-40 (LHD-WHT-WCGS-LAW)	1	812	2435	
	74/ 10-20-40 (LHD-WHT-WAW)	1	812	3430	
	76 90 (WHT)	1	812	2435	
7.038-7	RING, Gear Shift Operating Shaft Retainer				
	74/ 10-20-40 (LHD-WHT-WAW)	1	448	7864	
7.038-8	PLATE, Gear Shift Operating Shaft Stop				
	74/ 10-20-40 (LHD-WHT-WAW)	1	812	3429	
7.038-9	ATTACHING PARTS, Plate To Steering Column				
	SCREW, Tapping 74/ 10-20-40 (LHD-WHT-WAW)	2	320	8210	
7.075-1	BRACKET, Gear Shift Cross Shaft				
	74/ SIX (WHT-Except 90)	1	535	2592	
	74 V8 (WHT)	7.038	1	535	2148
	75/ V8 (WHT-Except 90)	1	535	4192	
7.075-2	ATTACHING PARTS, Bracket To Frame				
	BOLT, Hexagon 74/ WHT (Except 90)	17.670	2	G172463	
	SCREW, Tapping 76 90 (WHT)	17.670	2	G178434	

SHIFTING

7.535

7.075-3	BEARING, Gear Shift Cross Shaft Bracket 74/ WHT	1	535 2589
7.075-4	ATTACHING PARTS, Bearing To Cross Shaft Bracket BOLT, Hexagon 74/ WHT	17.670 2	G178434
7.080-1	SPRING, Cross Shaft Rattle 74/ WHT	1	535 2991
7.110-1	BELLCRANK, Column Gear Shift 74/ SIX (WHT-Except 90) 74 V8 (WHT) 75/ V8 (WHT-Except 90) 76 90 (WHT)	1 1 1 1	535 2152 535 2154 535 4190 535 3167
7.110-2	ATTACHING PARTS, Bellcrank To Transmission Lever PIN, Self-Locking..... 74/ WHT	29.140 1	400 0407
7.125-1	ROD, Hydramatic Transmission Gear Shift 74/ SIX (Except 90) 74 V8 75 10 (V8) 76 10-20-40 (V8) 75 20-40 (V8) 76 90 (WHT)	1 1 1 1 1 1	535 2146 535 2147 535 4193 535 5239 535 5239 535 3170
7.125-4a	ATTACHING PARTS, Hydramatic Transmission Gear Shift Rod To Column BUSHING 74/ GROWLET 74/ WASHER, Plain..... 74/ WASHER, Spring 74/ PIN, Self-Locking..... 74/	1 1 2 1 29.140 1	318 7696 318 7697 943 961 815 535 400 0407
7.125-6	TRUNNION, Gear Shift Rod 74/ WHT	1	947 629
7.125-7	ATTACHING PARTS, Trunnion To Shift Rod NUT, Hexagon 74 WHT NUT, Lock 75/ WHT	17.416 1 17.416 1	G442826 G9416531
7.125-9	CLIP, Gear Shift Rod Trunnion Retaining 74/ WHT	1	948 180
7.125-10	INSULATOR, Gear Shift Lever Trunnion To Bellcrank 74/ WHT	18.125 1	931 503
7.125-11	ATTACHING PARTS, Trunnion To Bellcrank WASHER, Plain 74/ WHT WASHER, Spring 74/ WHT PIN, Cotter 74/ WHT	17.814 1 1 17.460 1	G120394 815 535 G137159
7.130-5	LEVER, Hydramatic Transmission Gear Shift (On Transmission) 74/	1	535 2156
7.130-11	ATTACHING PARTS, Lever To Shaft WASHER, Lock 74/ NUT Jam 74/	17.820 1 17.410 1	G120382 G124829
7.535-1	BRACKET, Gear Selector Dial Lamp (Incl. Hood) 74/ WHT (WCGS-LAW)	7.039 1	319 6505
7.535-2	HOOD, Gear Selector (Incl. Filter) 74-75 WHT (WAW) 76 10-20-40 (WAT-WAW)	1 1	318 7833 535 5991
7.535-7	SOCKET, Gear Selector Dial Lamp 74/ 10-20-40 (LHD-WHT-WCGS-LAW) 74/ 10-20-40 (LHD-WHT-WAW) 76 90 (WHT)	1 1 1	448 7785 448 7846 448 7785

7.535

SHIFTING

7.535-7a ATTACHING PARTS, Socket To Housing

SCREW, Tapping.....	74/	10-20-40 (WHT-WCGS).....	1	448 8307
SCREW, Tapping.....	76	90 (WHT).....	1	448 8307

7.535-8 BULB, Gear Selector Dial Lamp

74/	WHT (WCGS-WAW).....	3.215	1	320 4552
76	10-20-40-90 (WHT-LAW).....		1	320 9598

7.535-9 PROTECTOR, Gear Selector Dial Lamp Wire

74/	10-20-40 (LHD-WHT-WCGS-LAW).....	3.321	1	448 7742
76	90 (WHT).....		1	448 7742

7.535-10 RETAINER, Gear Selector Dial Lamp Lens

74/	10-20-40 (LHD-WHT-WAW).....		1	448 7852
-----	-----------------------------	--	---	----------

7.536-1 POINTER, Gear Selector Dial

74/	WHT (LAW).....		1	321 5679
74/	WHT (WAW).....		1	319 6688

7.537-1 DIAL, Gear Selector Pointer

10-20-40 (LAW)

74	...(Less Bezel).....		1	535 1187
74/75	(Black)...(Incl. Bezel).....		1	535 1295
76	(Black)...(Incl. Bezel).....		1	535 5992
75	(Blue)...(Incl. Bezel).....		1	535 4090
76	(Blue)...(Incl. Bezel).....		1	535 5994
74	(Buff)...(Incl. Bezel).....		1	535 1297
74	(Cinnamon)...(Incl. Bezel).....		1	535 4030
74	(Green)...(Incl. Bezel).....		1	535 1296
75	(Green)...(Incl. Bezel).....		1	535 4089
76	(Green)...(Incl. Bezel).....		1	535 5993
74/75	(Tan)...(Incl. Bezel).....		1	535 4091
76	(Tan)...(Incl. Bezel).....		1	535 5995

90 (LAW-WHT)

76	(Black)...(Incl. Bezel).....		1	535 5992
----	------------------------------	--	---	----------

10-20-40 (WAW)

74	...(Less Bezel).....		1	535 2643
74/	(Black)...(Incl. Bezel).....		1	535 2722
75/	(Blue)...(Incl. Bezel).....		1	535 4093
74	(Buff)...(Incl. Bezel).....		1	535 2723
74	(Cinnamon)...(Incl. Bezel).....		1	535 4031
74	(Green)...(Incl. Bezel).....		1	535 2724
75/	(Green)...(Incl. Bezel).....		1	535 4092
74/	(Tan)...(Incl. Bezel).....		1	535 4094

7.537-2 ATTACHING PARTS, Dial To Directional Signal Switch Housing

CLIP, Spring.....	74/	WHT (WAW).....	2	319 6686
-------------------	-----	----------------	---	----------

7.538-1 SPRING, Gear Selector Dial Housing

74/	WHT (WCGS).....		2	319 6503
-----	-----------------	--	---	----------

7.539-1 HOOD, Gear Selector Dial Lamp

74/	WHT (LAW).....	7.535	1	319 6504
74/	WHT (WAW).....	7.535	1	319 6687