

## A

- AM and AM-FM stereo radio (Cherokee-Wagoneer-Truck) ..... 3-76
- AM radio (CJ models) ..... 3-75
- Absorbers, shock ..... 12-1
- Accessories ..... 3-82
- Adjust-O-Tilt steering column ..... 11-25
- Adjustment, alternator belt (six cyl with air conditioning) ..... 2-10
- Adjustment, antenna trimmer ..... 3-76
- Adjustment, auto trans manual linkage ..... 7-20
- Adjustment, automatic transmission linkage ..... B-9
- Adjustment, belt (V-8 engine with air conditioning) ..... 2-11
- Adjustment, control cable (heater) ..... 13-5
- Adjustment, clutch linkage ..... 5-5
- Adjustment, clutch release lever ..... 5-9
- Adjustment, dashpot ..... 4A-35
- Adjustment, fan and alternator belt ..... 2-10
- Adjustment, front axle turning angle ..... 10-9
- Adjustment, front wheel bearing (CJ models) ..... 9-37
- Adjustment, front wheel bearing (Cherokee, Wagoneer, Truck) ..... 9-37
- Adjustment, parking brake ..... 9-1
- Adjustment, rear wheel bearing ..... 9-37
- Adjustment, stoplamp switch ..... 9-2
- Adjustment, tailgate glass (Cherokee-Wagoneer) ..... 16-5
- Adjustments, axles-propeller shafts ..... 10-40
- Adjustments, brake pedal and linkage ..... 9-1
- Adjustments, manual steering gear ..... 11-33
- Air Guard System ..... 4A-7
- Air Guard System (V-8) ..... 4A-7
- Air Guard System (six-cyl) ..... 4A-7
- Air cleaner ..... 4-1
- Air conditioning compressor ..... 13A-11
- Air conditioning compressor front seal ..... 13A-13
- Air conditioning compressor valve leak diagnosis ..... 13A-11
- Air conditioning condenser and receiver/dryer assembly ..... 13A-16
- Air conditioning evaporator housing assembly .. 13A-16
- Air conditioning expansion valve service ..... 13A-20
- Air conditioning magnetic clutch ..... 13A-15
- Air conditioning normal operating temperatures and pressures ..... 13A-20
- Air conditioning performance diagnosis ..... 13A-2
- Air conditioning pressure diagnosis ..... 13A-3
- Air conditioning pressure gauge and manifold assembly ..... 13A-5
- Air conditioning service valves ..... 13A-5
- Air conditioning sight glass ..... 13A-7
- Air conditioning system ..... 13A-1
- Air conditioning system charging ..... 13A-10
- Air conditioning system leaks ..... 13A-9
- Air conditioning system troubleshooting ..... 13A-18
- Air conditioning temperature control thermostat 13A-20
- Air injection manifolds and tubes ..... 4A-11
- Air pump ..... 4A-7
- Air pump diagnosis ..... 4A-8
- Air pump operation ..... 4A-8
- Alignment, axle ..... 14-2
- Alignment, clutch housing ..... 5-8
- Alignment, frame ..... 14-2
- Alignment, front wheel ..... 11-38
- Alignment, hood ..... 14-12
- Alignment, steering column ..... 11-1
- Alignment, steering wheel spoke ..... 11-39
- Alternator belt adjustment (six cyl with air conditioning) ..... 2-10
- Alternator noise suppression ..... 3-80
- Alternator, Delco ..... 3-21
- Alternator, Motorcraft ..... 3-11
- Analyzer, ignition diagnosis with scope ..... 4A-31
- Antenna trimmer adjustment ..... 3-76
- Antenna, radio ..... 3-82
- Arm, windshield wiper ..... 17-5
- Assemblies, instrument panel and mounted ..... 18-1
- Assembly, air conditioning condenser and receiver/dryer ..... 13A-16
- Assembly, air conditioning evaporator housing .. 13A-16
- Assembly, air conditioning pressure gauge and manifold ..... 13A-5
- Assembly, auto trans governor ..... 7-3
- Auto tran hydraulic system ..... 7-3
- Auto trans diagnosis guides ..... 7-18
- Auto trans front servo ..... 7-3
- Auto trans governor assembly ..... 7-3
- Auto trans identification ..... 7-1
- Auto trans manual linkage adjustment ..... 7-20
- Auto trans modulator testing ..... 7-18
- Auto trans planetary gear train ..... 7-3
- Auto trans power flow ..... 7-1
- Auto trans pressure test and specifications ..... 7-7
- Auto trans pressure test diagnosis ..... 7-9
- Auto trans road testing ..... 7-6
- Auto trans service procedures (in car) ..... 7-20
- Auto trans service procedures (out of car) ..... 7-23
- Auto trans shift speed chart ..... 7-8
- Auto trans specifications ..... 7-64
- Auto trans torque specifications ..... 7-64
- Auto trans towing ..... 7-5
- Auto trans vacuum modulator ..... 7-3
- Automatic transmission ..... 7-1
- Automatic transmission fluid change ..... B-10
- Automatic transmission linkage adjustment ..... B-9
- Axle alignment ..... 14-2
- Axle differentials fluid change (front and rear) ..... B-10
- Axle testing and diagnosis ..... 10-1
- Axle tests ..... 10-1

**A**

(Continued)

Axle, front .....	10-3
Axle, rear .....	10-9
Axles-propeller shafts .....	10-1
Axles-propeller shafts adjustments .....	10-40
Axles-propeller shafts torque specifications .....	10-39

**B**

Backup lamps .....	3-72
Backup switches .....	3-72
Balancing, wheel .....	9-36
Bar, stabilizer .....	12-2
Batteries .....	3-2
Battery cables .....	B-1
Battery capacity rating chart .....	3-2
Battery charging .....	3-3
Battery electrolyte freezing temperature chart .....	3-4
Battery heavy load test .....	3-10
Battery hydrometer test .....	3-9
Battery maintenance .....	3-4
Battery reserve capacity rating .....	3-2
Battery self-discharge rate chart .....	3-9
Battery specific gravity reading .....	3-9
Battery storage .....	3-10
Battery test procedures .....	3-5
Battery testing .....	3-4
Battery-to-solenoid-voltage-drop test .....	3-40
Battery-to-starter-motor-voltage-drop test .....	3-40
Bearing, front spindle .....	10-8
Bearing, rear axle shaft and .....	10-11
Bearing, throwout .....	5-6
Bearings, connecting rod (V-8) .....	1B-29
Bearings, connecting rod (six-cyl) .....	1A-27
Bearings, crankshaft main (six-cyl) .....	1A-31
Bearings, crankshaft main (V-8) .....	1B-34
Belt adjustment (V-8 engine with air conditioning) .....	2-11
Belts, drive .....	B-5
Belts, seat .....	19-1
Belts, seat .....	19-3
Blades, windshield wiper .....	17-5
Bleeding, brake system .....	9-19
Block, cylinder (six-cyl) .....	1A-25
Block, cylinder (V-8) .....	1B-26
Bodies .....	14-1
Body construction .....	14-1
Body leaks .....	14-1
Body lubrication .....	B-3
Body water test procedure .....	14-1
Brake diagnosis .....	9-1
Brake drums .....	9-26
Brake fluids .....	9-13
Brake hydraulic system .....	9-13

Brake hydraulic system inspection procedure .....	9-13
Brake inspection .....	B-3
Brake master cylinder .....	9-14
Brake master cylinder (CJ models) .....	9-16
Brake master cylinder fill level .....	9-13
Brake pedal and linkage adjustments .....	9-1
Brake power unit service diagnosis .....	9-3
Brake size and application chart .....	9-41
Brake system bleeding .....	9-19
Brakes and wheels .....	9-1
Brakes and wheels torque specifications .....	9-40
Brakes, disc .....	9-27
Brakes, drum .....	9-21
Bulb, radio .....	3-82
Bumpers .....	14-13
Bushing, crankshaft pilot .....	5-7

**C**

CJ-5 and CJ-7 Models .....	A-1
Cables, battery .....	B-1
Cam lobe lift measurement (V-8) .....	1B-22
Cam lobe lift measurement (six-cyl) .....	1A-20
Camber .....	11-39
Camshaft and bearings (V-8) .....	1B-22
Camshaft and bearings (six-cyl) .....	1A-20
Camshaft identification (V-8) .....	1B-22
Canister, fuel vapor storage .....	4A-19
Cap, distributor .....	4A-30
Cap, fuel tank filler .....	4A-18
Cap, radiator .....	2-3
Cap, radiator .....	2-7
Capacities, fluid .....	B-12
Carburetion .....	4-8
Carburetion .....	4A-31
Carburetor Model YF-1 venturi .....	4-7
Carburetor Model 2100-2 venturi .....	4-20
Carburetor Model 4350-4 venturi .....	4-33
Carburetor overhaul (Model YF) .....	4-12
Carburetor overhaul (Model 2100) .....	4-26
Carburetor overhaul (Model 4350) .....	4-39
Carburetor service specifications .....	4-49
Cardan cross-type universal joint .....	10-38
Case, Model 20 transfer .....	8-1
Case, Quadra-Trac transfer .....	8-11
Caster .....	11-39
Catalyst replacement procedure .....	4A-17
Catalytic converter .....	4A-16
Catalytic converter .....	B-11
Catalytic converter operation .....	4A-16
Chain, timing (V-8) .....	1B-21
Chain, timing (six-cyl) .....	1A-19

## C

(Continued)

- Charging, air conditioning system ..... 13A-10  
 Chart, tire inflation pressure ..... 9-40  
 Chassis lubrication ..... B-3  
 Check, Quadra-Trac transfer case torque bias ..... 8-13  
 Checking system pressures (air conditioning) .... 13A-7  
 Cherokee Models ..... A-2  
 Choke linkage ..... 4A-35  
 Cigar lighter ..... 3-64  
 Clock ..... 3-64  
 Cluster, instrument ..... 3-54  
 Cluster, instrument (CJ) ..... 18-1  
 Cluster, instrument (Cherokee-Wagoneer-Truck) ..... 18-1  
 Clutch ..... 5-1  
 Clutch area noises ..... 5-5  
 Clutch driven plate ..... 5-6  
 Clutch housing alignment ..... 5-8  
 Clutch housing alignment specifications ..... 5-11  
 Clutch linkage adjustment ..... 5-5  
 Clutch release lever adjustment ..... 5-9  
 Clutch service diagnosis ..... 5-1  
 Clutch specifications ..... 5-11  
 Clutch torque specifications ..... 5-11  
 Clutch-related vibrations ..... 5-5  
 Clutch, air conditioning magnetic ..... 13A-15  
 Code, engine build date (six-cyl) ..... 1A-1  
 Code, engine build date (V-8) ..... 1B-1  
 Coil, ignition ..... 4A-30  
 Coil, ignition ..... 3-44  
 Column, Adjust-O-Tilt steering ..... 11-25  
 Columns, steering ..... 11-1  
 Combination valve (CJ models) ..... 9-17  
 Combination valve (Cherokee-Wagoneer-Truck) .... 9-18  
 Compressor, air conditioning ..... 13A-11  
 Condition, Quadra-Trac stick-slip ..... 8-12  
 Condition, spark plug ..... 4A-28  
 Connecting rod ..... 11-37  
 Connecting rod and piston assemblies (V-8) ..... 1B-28  
 Connecting rod and piston assemblies (six-cyl) ... 1A-26  
 Connecting rod bearing fitting chart (V-8) ..... 1B-29  
 Connecting rod bearing fitting chart (six-cyl) .... 1A-27  
 Connecting rod bearings (V-8) ..... 1B-29  
 Connecting rod bearings (six-cyl) ..... 1A-27  
 Connecting rods (V-8) ..... 1B-28  
 Connecting rods (six-cyl) ..... 1A-27  
 Control cable adjustment (heater) ..... 13-5  
 Controls, emission ..... 4A-1  
 Controls, heater and defroster ..... 13-1  
 Controls, wiper and washer ..... 17-5  
 Conversion of English and Metric Measures ..... A-6  
 Converter, catalytic ..... 4A-16  
 Converter, catalytic ..... B-11  
 Converter, torque ..... 7-2  
 Coolant ..... 2-9  
 Coolant, engine ..... B-4  
 Cooling system ..... 2-1  
 Cooling system (V-8) ..... 2-1  
 Cooling system (six-cyl) ..... 2-1  
 Cooling system components application chart ..... 2-16  
 Cooling system diagnosis ..... 2-3  
 Cooling system pressure test ..... 2-8  
 Cooling system specifications ..... 2-16  
 Cooling system tests ..... 2-6  
 Cooling system torque specifications ..... 2-15  
 Core, heater ..... 13-6  
 Courtesy lamps ..... 3-72  
 Crankshaft (V-8) ..... 1B-33  
 Crankshaft (six-cyl) ..... 1A-31  
 Crankshaft end play measurement (six-cyl) ..... 1A-31  
 Crankshaft end play measurement (V-8) ..... 1B-34  
 Crankshaft main bearings (six-cyl) ..... 1A-31  
 Crankshaft main bearings (V-8) ..... 1B-34  
 Crankshaft pilot bushing ..... 5-7  
 Crash pad (CJ) ..... 18-3  
 Crash pad (Cherokee-Wagoneer-Truck) ..... 18-3  
 Cruise command ..... 3-89  
 Cruise command diagnosis ..... 3-95  
 Cruise command schematic ..... 3-94  
 Cycle, refrigeration ..... 13A-4  
 Cylinder block (V-8) ..... 1B-26  
 Cylinder block (six-cyl) ..... 1A-25  
 Cylinder bore reconditioning (V-8) ..... 1B-27  
 Cylinder bore reconditioning (six cyl) ..... 1A-25  
 Cylinder head (V-8) ..... 1B-14  
 Cylinder head (six-cyl) ..... 1A-13  
 Cylinder head cover (six-cyl) ..... 1A-9  
 Cylinder head cover (V-8) ..... 1B-11  
 Cylinder head reconditioning (V-8) ..... 1B-15  
 Cylinder head reconditioning (six-cyl) ..... 1A-14  
 Cylinder head torque sequence (V-8) ..... 1B-15  
 Cylinder head torque sequence (six-cyl) ..... 1A-14  
 Cylinder leakage test diagnosis (six-cyl) ..... 1A-3  
 Cylinder, brake master ..... 9-14
- D**
- Damper, steering ..... 11-38  
 Dashpot adjustment ..... 4A-35  
 Decals, exterior ..... 20-5  
 Decimal equivalents ..... A-12  
 Defogger testing ..... 3-85  
 Defogger, tailgate window ..... 3-84  
 Defroster, heater and ..... 13-1  
 Delco alternator ..... 3-21  
 Delco alternator troubleshooting ..... 3-22  
 Diagnosis, air conditioning compressor valve  
 leak ..... 13A-11  
 Diagnosis, air conditioning performance ..... 13A-2



## E

(Continued)

- Engine cylinder leakage test diagnosis (V-8) ..... 1B-9  
 Engine drive belt tension specifications ..... 11-62  
 Engine drive belt tension specifications ..... 2-17  
 Engine flushing ..... 2-14  
 Engine holding fixture (V-8) ..... 1B-4  
 Engine holding fixture (six-cyl) ..... 1A-8  
 Engine identification (six-cyl) ..... 1A-1  
 Engine identification (V-8) ..... 1B-1  
 Engine idle speed and mixture setting  
   procedures ..... 4A-31  
 Engine idle speeds ..... B-5  
 Engine installation (V-8) ..... 1B-10  
 Engine installation (six-cyl) ..... 1A-9  
 Engine lubrication system (V-8) ..... 1B-2  
 Engine lubrication system (six-cyl) ..... 1A-2  
 Engine modifications ..... 4A-11  
 Engine mounting (V-8) ..... 1B-4  
 Engine mounting (six-cyl) ..... 1A-8  
 Engine oil change ..... B-4  
 Engine oil viscosity ..... B-4  
 Engine oversize or undersize components (V-8) .... 1B-2  
 Engine oversize or undersize components (six-  
   cyl) ..... 1A-2  
 Engine removal (V-8) ..... 1B-9  
 Engine removal (six-cyl) ..... 1A-8  
 Engine service diagnosis (V-8) ..... 1B-5  
 Engine service diagnosis (six-cyl) ..... 1A-5  
 Engine spark knock (ping) ..... 3-41  
 Engine specifications (V-8) ..... 1B-36  
 Engine specifications (six-cyl) ..... 1A-33  
 Engine torque specifications (V-8) ..... 1B-39  
 Engine torque specifications (six-cyl) ..... 1A-34  
 Engine, V-8 ..... 1B-1  
 Engine, six-cylinder ..... 1A-1  
 Engine identification (V-8) ..... 1B-1  
 Evacuating AC system ..... 13A-7  
 Exhaust Gas Recirculation (EGR) System ..... 4A-12  
 Exhaust back-pressure sensor ..... 4A-14  
 Exhaust back-pressure sensor test ..... 4A-15  
 Exhaust manifold (V-8) ..... 1B-14  
 Exhaust manifold heat valve ..... 4A-35  
 Exhaust manifold heat valve ..... B-8  
 Exhaust system inspection ..... B-4  
 Exhaust systems ..... 4A-35  
 Exhaust valve rotator (six-cyl) ..... 1A-10  
 Exterior decals ..... 20-5
- F**
- Fan and alternator belt adjustment ..... 2-10  
 Fan, Tempatrol viscous ..... 2-2  
 Fenders ..... 14-11  
 Filter, fuel ..... 4-2  
 Filter, oil (V-8) ..... 1B-24  
 Filter, oil (six-cyl) ..... 1A-22  
 Fixture, engine holding (V-8) ..... 1B-4  
 Fixture, engine holding (six-cyl) ..... 1A-8  
 Flasher, 4-way emergency (hazard warning) ..... 3-74  
 Fluid capacities ..... B-12  
 Fluid level checks ..... B-5  
 Fluids ..... B-2  
 Flywheel ..... 5-7  
 Flywheel and starter ring gear assembly (V-8) ... 1B-36  
 Flywheel and starter ring gear assembly (six-  
   cyl) ..... 1A-33  
 Folding windshield ..... 17-4  
 Frame alignment ..... 14-2  
 Frame construction ..... 14-2  
 Frame dimensions (CJ-5 model) ..... 14-3  
 Frame dimensions (CJ-7 model) ..... 14-4  
 Frame dimensions (Cherokee and Wagoneer) ..... 14-5  
 Frame dimensions (119-inch wheelbase Truck) .... 14-6  
 Frame dimensions (131-inch wheelbase Truck) .... 14-7  
 Frame straightening ..... 14-2  
 Fresh air ventilation ..... 13-3  
 Front axle ..... 10-3  
 Front axle housing ..... 10-3  
 Front axle identification ..... 10-3  
 Front axle pinion shaft oil seal ..... 10-3  
 Front axle shaft ..... 10-4  
 Front axle shaft seal ..... 10-8  
 Front axle shaft universal joint ..... 10-5  
 Front axle turning angle adjustment ..... 10-9  
 Front axle windup control device ..... 12-1  
 Front bucket seats ..... 19-1  
 Front door glass (Cherokee-Wagoneer-Truck) ..... 15-7  
 Front door vent assembly (Cherokee-Wagoneer-  
   Truck) ..... 15-7  
 Front door window regulator (CJ) ..... 15-1  
 Front door window regulator (Cherokee-  
   Wagoneer-Truck) ..... 15-8  
 Front end shimmy ..... 11-40  
 Front fender and apron ..... 14-11  
 Front seat assemblies ..... 19-1  
 Front spindle bearing ..... 10-8  
 Front steering knuckle ..... 10-6  
 Front steering knuckle ball stud ..... 10-6  
 Front wheel alignment ..... 11-38  
 Front wheel bearing adjustment (CJ models) ..... 9-37  
 Front wheel bearing adjustment (Cherokee,  
   Wagoneer, Truck) ..... 9-37  
 Fuel and temperature gauge diagnosis ..... 3-61  
 Fuel and temperature gauge diagnosis ..... 3-62  
 Fuel filter ..... 4-2  
 Fuel gauge and sending unit ..... 3-58  
 Fuel gauge calibration ..... 3-58  
 Fuel or temperature gauge tests ..... 3-58

**F**

(Continued)

Fuel pump	4-5
Fuel pump testing	4-7
Fuel requirements	B-1
Fuel return system	4-5
Fuel system	4-1
Fuel tank	4-2
Fuel tank	4A-18
Fuel tank filler cap	4A-18
Fuel tank filler tube	4-3
Fuel tank sending unit	4-3
Fuel tank vapor emission control system	4A-18
Fuel vapor return system	4-6
Fuel vapor storage canister	4A-19

**G**

Galvanized panels	14-8
Gear, manual steering	11-29
General	A-1
General dimensions	A-9
General information-vehicle identification	A-1
Glass, air conditioning sight	13A-7
Glove box assembly (CJ)	18-3
Glove box assembly (Cherokee-Wagoneer-Truck)	18-4
Grilles, radiator	14-9
Guide, tailgate electrical window diagnosis	16-6
Guides, auto trans diagnosis	7-18

**H**

Head, cylinder (V-8)	1B-14
Head, cylinder (six-cyl)	1A-13
Headlamp aiming procedure	3-67
Headlamp dimmer switch	3-67
Headlamp switch	3-67
Headlamps	3-66
Headlining	20-1
Heater and defroster	13-1
Heater and defroster controls	13-1
Heater and defroster operation	13-2
Heater control panel	13-5
Heater core	13-6
Heater-defroster blower motor	13-7
Heater-defroster fan control switch	13-4
Heater-defroster service diagnosis	13-4
Heater, engine block	2-14
Hinge replacement (CJ)	15-2
Hinge replacement (Cherokee-Wagoneer-Truck)	15-5
Hood alignment	14-12
Hood bumper	14-13
Hood lock	14-13

Hoods	14-12
Horn noise	3-82
Horns and horn relay	3-75
Housing, front axle	10-3
Housing, rear axle	10-10
Hub, rear axle	10-10
Hydraulic tappet leak-down test (V-8)	1B-18
Hydraulic tappet leak-down test (six-cyl)	1A-16
Hydraulic valve tappets (V-8)	1B-17
Hydraulic valve tappets (six-cyl)	1A-15

**I**

Identification, auto trans	7-1
Identification, engine (V-8)	1B-1
Identification, engine (six-cyl)	1A-1
Identification, front axle	10-3
Identification, man trans	6-2
Identification, radiator	2-13
Identification, rear axle	10-9
Identification, starter motor	3-32
Ignition coil	4A-30
Ignition coil	3-44
Ignition diagnosis with scope analyzer	4A-31
Ignition switch	3-64
Ignition switch test	3-65
Ignition system	4A-28
Ignition system	3-41
Ignition system diagnosis	3-41
Ignition system test	3-47
Ignition system tests	3-46
Ignition system troubleshooting	3-47
Ignition timing procedure	4A-30
Infrared (IR) analyzer procedure (CJ w/six-cyl) eng w/o cat con)	4A-34
Initial ignition timing	4A-30
Inspection and adjustment, manual transmission clutch	B-9
Inspection, brake	B-3
Inspection, exhaust system	B-4
Inspection, power steering pump	11-59
Instrument cluster	3-54
Instrument cluster (CJ)	18-1
Instrument cluster (Cherokee-Wagoneer-Truck)	18-1
Instrument cluster assembly (CJ models)	3-55
Instrument cluster (Cherokee-Wagoneer-Truck)	3-56
Instrument panel (CJ)	18-2
Instrument panel (Cherokee-Wagoneer-Truck)	18-2
Instrument panel and mounted assemblies	18-1
Instrument panel tailgate window switch	3-86
Instrument panel (CJ models)	3-55
Intake and exhaust manifolds (six-cyl)	1A-12
Intake manifold (V-8)	1B-13

## J

Joint, cardan cross-type universal .....	10-38
Joint, double cardan .....	10-38
Joint, front axle shaft universal .....	10-5
Joints, propeller shafts and universal .....	10-38

## K

Key lock (Cherokee-Wagoneer-Truck) .....	15-5
Keys and locks .....	A-5
Kits, paint repair (molded top) .....	20-2
Knuckle, front steering .....	10-6

## L

Lamp, license plate .....	3-71
Lamps, backup .....	3-72
Lamps, courtesy .....	3-72
Lamps, directional .....	3-67
Lamps, dome .....	3-72
Lamps, parking .....	3-67
Lamps, rear directional .....	3-69
Lamps, stop .....	3-69
Lamps, tail .....	3-69
Latch and remote control (Cherokee-Wagoneer-Truck) .....	15-6
Leaks, air conditioning system .....	13A-9
Leaks, body .....	14-1
License plate lamp .....	3-71
Liftgate .....	20-2
Lighter, cigar .....	3-64
Lighting systems .....	3-66
Linkage, choke .....	4A-35
Linkage, steering .....	11-36
Liquid check valve .....	4A-19
Lock cylinder coding (Cherokee-Wagoneer-Truck) .....	15-5
Lubrication, Quadra-Trac transfer case .....	8-13
Lubrication, Trac-Lok .....	10-32
Lubrication, body .....	B-3
Lubrication, chassis .....	B-3
Lubrication, man trans .....	6-26
Luggage rack .....	16-7

## M

Magnetic clutch electrical diagnosis .....	13A-15
Magnetic clutch troubleshooting .....	13A-19
Main bearing fitting chart (V-8) .....	1B-35
Main bearing fitting chart (six-cyl) .....	1A-32

Maintenance .....	B-1
Maintenance after first 200 miles .....	B-4
Maintenance after first 5,000 miles .....	B-5
Maintenance every 10,000 miles .....	B-8
Maintenance every 15,000 miles .....	B-9
Maintenance every 25,000 miles .....	B-9
Maintenance every 25,000 miles/months .....	B-4
Maintenance every 30,000 miles .....	B-10
Maintenance every 5,000 miles .....	B-5
Maintenance every 5,000 miles/months .....	B-4
Maintenance services scheduled by accumulated mileage .....	B-4
Maintenance services scheduled by mileage or time intervals .....	B-1
Maintenance, PCV air inlet filter .....	4A-21
Maintenance, battery .....	3-4
Maintenance, emission control .....	4A-27
Maintenance, unscheduled .....	B-11
Man trans Model T-15A 3-speed .....	6-11
Man trans Model T-150 3-speed .....	6-3
Man trans Model T-18 4-speed .....	6-18
Man trans identification .....	6-2
Man trans lubrication .....	6-26
Man trans specifications .....	6-26
Man trans torque specifications .....	6-26
Manifold, intake (V-8) .....	1B-13
Manifold, exhaust (V-8) .....	1B-14
Manifolds, intake and exhaust (six-cyl) .....	1A-12
Manual steering gear .....	11-29
Manual steering gear adjustments .....	11-33
Manual steering gear service diagnosis .....	11-30
Manual steering gear specifications .....	11-62
Manual transmission .....	6-1
Manual transmission and Model 20 transfer case fluid change .....	B-10
Manual transmission clutch inspection and adjustment .....	B-9
Marker, side .....	3-67
Master cylinder (CJ models) .....	9-16
Master cylinder (Cherokee-Wagoneer-Truck) .....	9-17
Mechanical maintenance schedule .....	B-1
Mechanical maintenance schedule .....	B-2
Metric system .....	A-8
Mirror, rear view .....	17-3
Model 20 transfer case .....	8-1
Model 20 transfer case service diagnosis .....	8-4
Model 20 transfer case service procedures-in vehicle .....	8-2
Model 20 transfer case service procedures-out of vehicle .....	8-5
Model 20 transfer case torque specifications .....	8-30
Modifications, engine .....	4A-11
Modulator, auto trans vacuum .....	7-3
Molded top .....	20-2
Molded top (CJ-7) .....	15-1



## M

(Continued)

Motor, heater-defroster blower .....	13-7
Motor, starter .....	3-32
Motor, tailgate window .....	3-88
Motor, wiper two-speed (CJ) .....	17-7
Motor, wiper two-speed (Cherokee-Wagoneer-Truck) .....	17-7
Motorcraft alternator .....	3-11
Motorcraft alternator testing .....	3-15
Motorcraft alternator troubleshooting .....	3-13

## O

Odometer setting procedure .....	3-63
Oil filter (V-8) .....	1B-24
Oil filter (six-cyl) .....	1A-22
Oil filter change .....	B-4
Oil pan (V-8) .....	1B-24
Oil pan (six-cyl) .....	1A-21
Oil pressure gauge and sending unit test .....	3-57
Oil pressure gauge calibrations .....	3-57
Oil pressure relief valve (V-8) .....	1B-24
Oil pump (V-8) .....	1B-24
Oil pump (six-cyl) .....	1A-23
Operation, heater and defroster .....	13-2
Outside door handle (CJ) .....	15-2
Outside door handle (Cherokee-Wagoneer-Truck) .....	15-5
Overhaul, carburetor .....	4-12
Overhaul, differential (AMC/Jeep axle) .....	10-17
Overhaul, differential (axle Models 30-44-60) .....	10-25
Overhaul, disc brake caliper .....	9-33
Overlays .....	20-7

## P

PCV air inlet filter maintenance .....	4A-21
PCV system (V-8) .....	4A-21
PCV system (six-cyl) .....	4A-20
PCV valve test .....	4A-21
Pad, crash (CJ) .....	18-3
Pad, crash (Cherokee-Wagoneer-Truck) .....	18-3
Paint option number .....	A-4
Paint repair kits (molded top) .....	20-2
Pan, oil (V-8) .....	1B-24
Pan, oil (six-cyl) .....	1A-21
Panel, heater control .....	13-5
Panel, instrument (CJ) .....	18-2
Panel, instrument Cherokee-Wagoneer-Truck .....	18-2
Panels .....	14-8
Panels, galvanized .....	14-8

Panels, rear quarter .....	14-8
Parking brake adjustment .....	9-1
Parking lamps .....	3-67
Pawl, tilt lock .....	19-2
Pinion angle chart .....	10-40
Pins, piston (V-8) .....	1B-31
Pins, piston (six-cyl) .....	1A-30
Piston fitting (V-8) .....	1B-31
Piston fitting (six-cyl) .....	1A-29
Piston pins (V-8) .....	1B-31
Piston pins (six-cyl) .....	1A-30
Piston rings (V-8) .....	1B-32
Piston rings (six-cyl) .....	1A-29
Pistons (six-cyl) .....	1A-28
Pistons (V-8) .....	1B-31
Pivot vent window (Cherokee) .....	15-10
Plate, vehicle identification .....	A-4
Plates, restrictor .....	4A-15
Plugs, spark .....	4A-28
Positive Crankcase Ventilation (PCV) system .....	4A-20
Positive Crankcase Ventilation (PCV) valve .....	4A-21
Power brake diagnosis .....	9-2
Power brake units .....	9-14
Power steering .....	11-40
Power steering gear service .....	11-44
Power steering gear specifications .....	11-62
Power steering periodic maintenance .....	11-44
Power steering pump inspection .....	11-59
Power steering pump service .....	11-57
Power steering pump specifications .....	11-62
Power train combinations charts .....	A-10
Power unit service .....	9-14
Precautions, refrigerant safety .....	13A-5
Pressures, air conditioning normal operating temperatures and .....	13A-20
Propeller shafts and universal joints .....	10-38
Pump, air .....	4A-7
Pump, oil (six-cyl) .....	1A-23
Pump, oil (V-8) .....	1B-24
Pump, water .....	2-6
Pump, windshield washer .....	17-12

## Q

Quadra Trac transfer case lubrication .....	8-13
Quadra-Trac emergency drive .....	8-11
Quadra-Trac reduction unit .....	8-11
Quadra-Trac stick-slip condition .....	8-12
Quadra-Trac transfer case .....	8-11
Quadra-Trac transfer case .....	B-11
Quadra-Trac transfer case torque bias check .....	8-13
Quarter, doors and rear .....	15-1



## R

Rack, luggage ..... 16-7  
 Radiator ..... 2-13  
 Radiator cap ..... 2-3  
 Radiator cap ..... 2-7  
 Radiator grilles ..... 14-9  
 Radiator identification ..... 2-13  
 Radiator, reverse flushing ..... 2-14  
 Radio antenna ..... 3-82  
 Radio bulb ..... 3-82  
 Radio interference diagnosis ..... 3-78  
 Radio polarity ..... 3-76  
 Radio reception characteristics ..... 3-77  
 Radio speaker harness test ..... 3-83  
 Radio speakers ..... 3-83  
 Readers comments ..... A-13  
 Rear axle ..... 10-9  
 Rear axle housing ..... 10-10  
 Rear axle hub ..... 10-10  
 Rear axle identification ..... 10-9  
 Rear axle pinion shaft oil seal ..... 10-14  
 Rear axle shaft and bearing ..... 10-11  
 Rear directional lamps ..... 3-69  
 Rear door glass (wagoner) ..... 15-8  
 Rear door remote control and lock lever  
   (Wagoner) ..... 15-8  
 Rear door vent assembly (Wagoner) ..... 15-9  
 Rear main bearing oil seal (V-8) ..... 1B-25  
 Rear main bearing oil seal (six-cyl) ..... 1A-24  
 Rear quarter panels ..... 14-8  
 Rear quarter trim panel (Cherokee-Wagoner) ... 15-10  
 Rear seat assemblies ..... 19-2  
 Rear view mirror ..... 17-3  
 Rear wheel bearing adjustment ..... 9-37  
 Rear window ..... 17-4  
 Rear window regulator (Wagoner) ..... 15-10  
 Recommended lubricants ..... B-12  
 Reconditioning, cylinder head (V-8) ..... 1B-15  
 Reconditioning, cylinder head (six-cyl) ..... 1A-14  
 Refacing, valve seat (six-cyl) ..... 1A-14  
 Refacing, valve seat (V-8) ..... 1B-16  
 Refrigerant safety precautions ..... 13A-5  
 Refrigeration cycle ..... 13A-4  
 Regulator, tailgate window (Cherokee-  
   Wagoner) ..... 16-5  
 Restrictor plates ..... 4A-15  
 Reverse flushing radiator ..... 2-14  
 Rings, piston (V-8) ..... 1B-32  
 Rings, piston (six-cyl) ..... 1A-29  
 Rocker arm assembly (V-8) ..... 1B-11  
 Rocker arm assembly (six-cyl) ..... 1A-10  
 Rod, connecting ..... 11-37  
 Rod, tie ..... 11-36  
 Rods, connecting (V-8) ..... 1B-28  
 Rods, connecting (six-cyl) ..... 1A-27  
 Rotor, distributor ..... 4A-30

## S

Schematic, cruise command ..... 3-94  
 Scope diagnosis pattern chart ..... 4A-31  
 Seal, air conditioning compressor front ..... 13A-13  
 Seal, front axle pinion shaft oil ..... 10-3  
 Seal, front axle shaft ..... 10-8  
 Seal, rear axle pinion shaft oil ..... 10-14  
 Seal, rear main bearing oil (V-8) ..... 1B-25  
 Seal, rear main bearing oil (six-cyl) ..... 1A-24  
 Seat assemblies and adjusters ..... 19-1  
 Seat belts ..... 19-1  
 Seat belts ..... 19-3  
 Seats, front bucket ..... 19-1  
 Sensor/trigger wheel ..... 3-44  
 Sensor, exhaust back-pressure ..... 4A-14  
 Service manual improvements ..... A-6  
 Service, air conditioning expansion valve ..... 13A-20  
 Servo, auto trans front ..... 7-3  
 Shaft, front axle ..... 10-4  
 Shaft, transmission clutch ..... 5-8  
 Shafts, axles-propeller ..... 10-1  
 Shimmy, front end ..... 11-40  
 Shock absorbers ..... 12-1  
 Short engine assembly (V-8) ..... 1B-36  
 Short engine assembly (six-cyl) ..... 1A-33  
 Side marker ..... 3-67  
 Six-cylinder engine ..... 1A-1  
 Solenoid control switch ..... 4A-24  
 Solenoid vacuum valve ..... 4A-24  
 Solenoid voltage drop test ..... 3-40  
 Spark CTO test ..... 4A-27  
 Spark coolant temperature override switch  
   (spark CTO) ..... 4A-26  
 Spark plug condition ..... 4A-28  
 Spark plug gap check ..... 4A-29  
 Spark plug wire resistance values ..... 4A-30  
 Spark plug wire test ..... 4A-30  
 Spark plug wires ..... 4A-29  
 Spark plugs ..... 4A-28  
 Speakers, radio ..... 3-83  
 Special sales request and order number  
   (SSR&O) ..... A-4  
 Special tools ..... A-6  
 Specifications, auto trans ..... 7-64  
 Specifications, auto trans torque ..... 7-64  
 Specifications, axles-propeller shafts torque ..... 10-39  
 Specifications, brakes and wheels torque ..... 9-40  
 Specifications, carburetor service ..... 4-49  
 Specifications, clutch ..... 5-11  
 Specifications, clutch housing alignment ..... 5-11  
 Specifications, clutch torque ..... 5-11  
 Specifications, cooling system ..... 2-16  
 Specifications, cooling system torque ..... 2-15  
 Specifications, electrical system torque ..... 3-99  
 Specifications, engine (six-cyl) ..... 1A-33  
 Specifications, engine (V-8) ..... 1B-36

## S

(Continued)

Specifications, engine drive belt tension ..... 11-62  
 Specifications, engine drive belt tension ..... 2-17  
 Specifications, engine torque (V-8) ..... 1B-39  
 Specifications, engine torque (six-cyl) ..... 1A-34  
 Specifications, man trans ..... 6-26  
 Specifications, man trans torque ..... 6-26  
 Specifications, manual steering gear ..... 11-62  
 Specifications, Model 20 transfer case torque ..... 8-30  
 Specifications, power steering gear ..... 11-62  
 Specifications, power steering pump ..... 11-62  
 Specifications, steering gear torque ..... 11-63  
 Specifications, suspension system torque ..... 12-7  
 Specifications, transfer case ..... 8-30  
 Specifications, tune-up ..... 4A-40  
 Specifications, wheel alignment ..... 11-62  
 Speedometer ..... 3-60  
 Speedometer cable inspection ..... 3-63  
 Speedometer calibration ..... 3-63  
 Speeds, engine idle ..... B-5  
 Springs (suspension) ..... 12-1  
 Stabilizer bar ..... 12-2  
 Standard differential ..... 10-16  
 Standard torque specifications ..... A-7  
 Starter cable test ..... 3-40  
 Starter motor ..... 3-32  
 Starter motor diagnosis ..... 3-36  
 Starter motor ground voltage drop test ..... 3-40  
 Starter motor identification ..... 3-32  
 Starter motor solenoid pull-in winding test ..... 3-40  
 Starter solenoid test ..... 3-39  
 Starting system ..... 3-31  
 Stationary rear quarter window (CJ) ..... 15-3  
 Stationary vent window (CJ) ..... 15-3  
 Stationary window (Cherokee) ..... 15-11  
 Stationary window (Wagoneer) ..... 15-11  
 Steering ..... 11-1  
 Steering column (automatic transmission) ..... 11-20  
 Steering column (manual transmission) ..... 11-12  
 Steering column alignment ..... 11-1  
 Steering column service diagnosis ..... 11-2  
 Steering columns ..... 11-1  
 Steering damper ..... 11-38  
 Steering gear and pump service diagnosis ..... 11-45  
 Steering gear torque specifications ..... 11-63  
 Steering linkage ..... 11-36  
 Steering wheel spoke alignment ..... 11-39  
 Steering, power ..... 11-40  
 Steering, variable ratio power steering ..... 11-41  
 Stop lamps ..... 3-69  
 Stoplamp switch adjustment ..... 9-2  
 Stud, front steering knuckle ball ..... 10-6  
 Suspension ..... 12-1  
 Suspension system torque specifications ..... 12-7  
 Switch, EGR CTO ..... 4A-14  
 Switch, directional signal ..... 3-73

Switch, headlamp ..... 3-67  
 Switch, headlamp dimmer ..... 3-67  
 Switch, heater-defroster fan control ..... 13-4  
 Switch, ignition ..... 3-64  
 Switch, instrument panel tailgate window ..... 3-86  
 Switch, solenoid control ..... 4A-24  
 Switch, tailgate window ..... 3-86  
 Switch, tailgate window safety ..... 3-87  
 Switches, backup ..... 3-72  
 Symptoms, Trac-Lok trouble ..... 10-32  
 System, PCV (V-8) ..... 4A-21  
 System, auto tran hydraulic ..... 7-3  
 System, engine lubrication (V-8) ..... 1B-2  
 System, engine lubrication (six-cyl) ..... 1A-2  
 Systems, exhaust ..... 4A-35  
 Systems, lighting ..... 3-66

## T

TAC operational test (V-8) ..... 4A-23  
 TAC operational test (six-cyl) ..... 4A-22  
 TAC system (V-8) ..... 4A-23  
 TAC system (six-cyl) ..... 4A-22  
 TCS system (V-8) ..... 4A-25  
 TCS system (six-cyl) ..... 4A-25  
 TCS system test ..... 4A-26  
 TCS test ..... 4A-24  
 Tail lamps ..... 3-69  
 Tailgate ..... 16-1  
 Tailgate (CJ-5) ..... 16-1  
 Tailgate (CJ-7) ..... 16-1  
 Tailgate (Cherokee-Wagoneer) ..... 16-2  
 Tailgate electrical window diagnosis guide ..... 16-6  
 Tailgate glass adjustment (Cherokee-wagoneer) ..... 16-5  
 Tailgate truck ..... 16-5  
 Tailgate window defogger ..... 3-84  
 Tailgate window motor ..... 3-88  
 Tailgate window regulator (Cherokee-Wagoneer) ..... 16-5  
 Tailgate window safety switch ..... 3-87  
 Tailgate window switch ..... 3-86  
 Tailgate window, electrical (Cherokee-Wagoneer) ..... 16-6  
 Tank, fuel ..... 4-2  
 Tank, fuel ..... 4A-18  
 Tappets, hydraulic valve (six-cyl) ..... 1A-15  
 Tappets, hydraulic valve (V-8) ..... 1B-17  
 Tempatrol fan test ..... 2-7  
 Tempatrol viscous fan ..... 2-2  
 Temperature gauge and sending unit ..... 3-58  
 Temperature gauge calibration ..... 3-58  
 Test and specifications, auto trans press ..... 7-7  
 Test, EGR CTO ..... 4A-14  
 Test, EGR delay valve ..... 4A-16

## T

(Continued)

- |   |        |   |        |
|---|--------|---|--------|
| Test, EGR valve .....   | 4A-13  | Timing mark location (V-8) .....  | 4A-31  |
| Test, PCV valve .....   | 4A-21  | Timing mark location (six-cyl) .....                                      | 4A-31  |
| Test, TCS .....   | 4A-24  | Timing, initial ignition .....  | 4A-30  |
| Test, battery heavy load .....                                | 3-10   | Tire care .....   | 9-39   |
| Test, battery hydrometer .....                                | 3-9    | Tire inflation pressure chart .....                                       | 9-40   |
| Test, battery-to-solenoid-voltage-drop .....                  | 3-40   | Tire noise tests .....  | 10-1   |
| Test, battery-to-starter-motor-voltage-drop .....             | 3-40   | Tire rotation .....   | 9-39   |
| Test, cooling system .....                                    | 2-6    | Tire service .....  | 9-37   |
| Test, cooling system pressure .....                           | 2-8    | Tires .....   | 9-37   |
| Test, distributor advance .....                               | 4A-30  | Tires .....   | B-12   |
| Test, diverter .....  | 4A-10  | Tires, wheels and .....   | 9-36   |
| Test, engine cylinder leakage (V-8) .....                     | 1B-9   | Toe-in .....  | 11-38  |
| Test, engine cylinder leakage (six-cyl) .....                 | 1A-3   | Top, molded .....   | 20-2   |
| Test, exhaust back-pressure sensor .....                      | 4A-15  | Torque converter .....  | 7-2    |
| Test, hydraulic tappet leak-down (six-cyl) .....              | 1A-16  | Torx-head fasteners .....   | A-7    |
| Test, hydraulic tappet leak-down (V-8) .....                  | 1B-18  | Towing (Model 20 transfer case) .....                                     | 8-1    |
| Test, ignition switch .....                                   | 3-65   | Towing (Quadra-Trac transfer case) .....                                  | 8-12   |
| Test, ignition system .....                                   | 3-47   | Towing, auto trans .....  | 7-5    |
| Test, radio speaker harness .....                             | 3-83   | Trac-Lok lubrication .....  | 10-32  |
| Test, solenoid voltage drop .....                             | 3-40   | Trac-Lok operation .....  | 10-32  |
| Test, spark CTO .....   | 4A-27  | Trac-Lok trouble symptoms .....   | 10-32  |
| Test, spark plug wire .....                                   | 4A-30  | Trac-Lok differential .....   | 10-32  |
| Test, starter cable .....                                     | 3-40   | Trailer towing packages .....   | 3-98   |
| Test, starter motor ground voltage drop .....                 | 3-40   | Transfer case .....   | 8-1    |
| Test, starter motor solenoid pull-in winding .....            | 3-40   | Transfer case shift control lever case<br>(Cherokee-Wagoneer-Truck) ..... | B-10   |
| Test, starter solenoid .....                                  | 3-39   | Transfer case shift linkage (CJ models) .....                             | B-10   |
| Test, tempatrol fan .....                                     | 2-7    | Transfer case specifications .....  | 8-30   |
| Test, valve spring tension (V-8) .....                        | 1B-13  | Transmission Controlled Spark (TCS)<br>System .....                       | 4A-24  |
| Test, valve spring tension (six-cyl) .....                    | 1A-11  | Transmission clutch shaft .....   | 5-8    |
| Testing at the instrument cluster (CJ models) .....           | 3-58   | Transmission oil cooler leakage .....                                     | 2-9    |
| Testing, Motorcraft alternator .....                          | 3-15   | Transmission, automatic .....   | 7-1    |
| Testing, auto trans modulator .....                           | 7-18   | Transmission, manual .....  | 6-1    |
| Testing, auto trans road .....                                | 7-6    | Troubleshooting, Delco alternator .....                                   | 3-22   |
| Testing, battery .....  | 3-4    | Troubleshooting, Motorcraft alternator .....                              | 3-13   |
| Testing, defogger .....                                       | 3-85   | Troubleshooting, air conditioning system .....                            | 13A-18 |
| Testing, fuel pump .....                                      | 4-7    | Troubleshooting, ignition system .....                                    | 3-47   |
| Tests, axle .....   | 10-1   | Troubleshooting, magnetic clutch .....                                    | 13A-19 |
| Tests, cooling system .....                                   | 2-6    | Troubleshooting, wiper motor (CJ) .....                                   | 17-8   |
| Tests, fuel or temperature gauge .....                        | 3-58   | Troubleshooting, wiper motor (Cherokee-<br>Wagoneer-Truck) .....          | 17-9   |
| Tests, ignition system .....                                  | 3-46   | Truck Models .....  | A-4    |
| Tests, tire noise .....                                       | 10-1   | Tube, fuel tank filler .....  | 4-3    |
| Tests, wheel bearing .....                                    | 10-1   | Tune-up (CJ models) .....   | B-10   |
| Thermostat .....  | 2-7    | Tune-up (Cherokee-Wagoneer-Truck) .....                                   | B-9    |
| Thermostat .....  | 2-13   | Tune-up, complete precision .....   | 4A-28  |
| Thermostat, air conditioning temperature<br>control .....     | 13A-20 | Tune-up, specifications .....   | 4A-40  |
| Thermostatically Controlled Air Cleaner<br>(TAC) system ..... | 4A-22  | Turn and stop signals .....   | 3-82   |
| Throwout bearing .....  | 5-6    |   |        |
| Tie rod .....   | 11-36  |   |        |
| Tilt lock pawl .....  | 19-2   |   |        |
| Timing case cover (V-8) .....                                 | 1B-19  |   |        |
| Timing case cover (six-cyl) .....                             | 1A-18  |   |        |
| Timing chain (V-8) .....                                      | 1B-21  |   |        |
| Timing chain (six-cyl) .....                                  | 1A-19  |   |        |

## U

- |   |       |
|---|-------|
| US Emission Control Service (CJ models) .....                   | 4A-28 |
| US Emission Control Service (Cherokee-<br>Wagoneer-Truck) ..... | 4A-28 |

## U

(Continued)

Unit, Quadra-Trac reduction .....	8-11
Unit, fuel tank sending .....	4-3
Universal joint service .....	10-38
Unscheduled maintenance .....	B-11

## V

V-8 engine .....	1B-1
Vacuum Throttle Modulating System (VTM) .....	4A-23
Valve guide reamers (V-8) .....	1B-16
Valve guide reamers (six-cyl) .....	1A-15
Valve guides (V-8) .....	1B-16
Valve guides (six-cyl) .....	1A-15
Valve reconditioning (V-8) .....	1B-16
Valve reconditioning (six-cyl) .....	1A-14
Valve seat refacing (V-8) .....	1B-16
Valve seat refacing (six-cyl) .....	1A-14
Valve spring tension test (V-8) .....	1B-13
Valve spring tension test (six-cyl) .....	1A-11
Valve spring/valve stem oil deflector (V-8) .....	1B-12
Valve spring/valve stem oil deflector (six-cyl) .....	1A-10
Valve stem-to-guide clearance (six-cyl) .....	1A-15
Valve stem-to-guide clearance (V-8) .....	1B-16
Valve timing check (V-8) .....	1B-21
Valve timing check (six-cyl) .....	1A-19
Valve, EGR .....	4A-12
Valve, EGR delay .....	4A-16
Valve, Positive Crankcase Ventilation (PCV) .....	4A-21
Valve, diverter (bypass) .....	4A-10
Valve, exhaust manifold heat .....	4A-35
Valve, exhaust manifold heat .....	B-8
Valve, liquid check .....	4A-19
Valve, oil pressure relief (V-8) .....	1B-24
Valve, solenoid vacuum .....	4A-24
Valve, hydraulic tappets (six-cyl) .....	1A-15
Valve, hydraulic tappets (V-8) .....	1B-17
Valves, air conditioning service .....	13A-5
Variable ratio power steering .....	11-41
Vehicle identification .....	A-4
Vehicle identification number (VIN) .....	A-4
Vehicle identification plate .....	A-4
Vent glass replacement .....	15-8
Ventilation, fresh air .....	13-3

Vibration damper (V-8) .....	1B-19
Vibration damper (six-cyl) .....	1A-17
Vibrations, drive line .....	10-2
VIN decoding chart .....	A-4
Viscosity, engine oil .....	B-4
Voltmeter .....	3-56

## W

Wagoneer Models .....	A-3
Water pump .....	2-6
Water pump service .....	2-11
Water shield (CJ) .....	15-2
Water shield (Cherokee-Wagoneer-Truck) .....	15-4
Wheel alignment specifications .....	11-62
Wheel and tire static .....	3-81
Wheel balancing .....	9-36
Wheel bearing service .....	9-36
Wheel bearing tests .....	10-1
Wheel-to-hub nuts .....	B-4
Wheels .....	9-36
Wheels and tires .....	9-36
Wheels, brake and .....	9-1
Window regulator (CJ) .....	15-1
Window, electrically operated tailgate .....	3-86
Window, rear .....	17-4
Windshield .....	17-1
Windshield glass (CJ) .....	17-1
Windshield glass (Cherokee-Wagoneer-Truck) .....	17-2
Windshield washer solution .....	B-7
Windshield wiper .....	17-5
Windshield wiper arm .....	17-5
Windshield wiper blades .....	17-5
Windshield, folding .....	17-4
Windshield washer pump .....	17-12
Wiper and washer controls .....	17-5
Wiper motor troubleshooting (CJ) .....	17-8
Wiper motor troubleshooting (Cherokee- Wagoneer-Truck) .....	17-9
Wiper motor two-speed (CJ) .....	17-7
Wiper motor two-speed (Cherokee-Wagoneer- Truck) .....	17-7
Wiper, windshield .....	17-5
Wires, spark plug .....	4A-29